

Lyd on/off på HM 270 MS 3/8 forseglingsapparat.

Ældre model:

SWITCH OFF THE BUZZER

1. Pull the plug out of the socket
2. Close the welding beam with the hand-operated lever
3. Pull the plug into the socket
4. Open the welding beam with the hand-operated lever

SWITCH ON THE BUZZER

1. Pull the plug out of the socket
2. Close the welding beam with the hand-operated lever
3. Pull the plug into the socket
4. Open the welding beam with the hand-operated lever

Ny model:

3.2 Switching the tone off and on

3.2.1 Switching the tone off

1. Switch off the device
2. Close the sealing dies
3. Switch the device on and open and close the sealing stamp 3 times inside 7 seconds.
Afterwards the device will give a short tone.

3.2.2 Switching the tone on

1. Switch off the device
2. Close the sealing dies
3. Switch the device on and open and close the sealing stamp 3 times inside 7 seconds.
Afterwards the device will give a long tone